



# Play Maker™


## Safety Guide & Building Instructions




Front View



Back View



Pallet



Area Requirements

**We're Here To Help!**

Call Toll Free **1-888-752-9782**  
Customer Service: Monday - Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

**PS 7456**

# SAFETY

- This product is intended for single-family residential use only, by children ages two to ten and a maximum weight of 105 pounds. Any recommendation over 10 years of age or 105 pounds exceeds the upper limits specified in the American Society for Testing and Materials (ASTM) Home Playground Safety Standard. In order for PlayStar to comply with the ASTM Standard, we cannot recommend anyone above these limits.
- It is a misuse of this product when installed or used in places of public assembly such as schools or parks.
- Follow the instructions provided, do not alter its design in any way.
- Construction requires at least two adults capable of heavy lifting.
- Thoroughly read all safety instructions before beginning.
- Children must remain clear of construction site until this product is properly installed and ready for use.
- Save these instructions in the event the manufacturer has to be contacted.

## The Consumer Product Safety Commission provides the following consumer information for your Home Playground Equipment

### Select Protective Surfacing

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

*NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are generally not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.*

### Loose-Fill Materials

PlayStar Playsets require fall-height protection from eight feet.

- Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch / chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for

equipment up to 8 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9-inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain at least a 9-inch depth.

- Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Check and maintain the depth of the loose-fill surfacing material. To maintain the right amount of loose-fill materials, mark the correct level on play equipment support posts. That way you can easily see when to replenish and/or redistribute the surfacing.
- **Do not** install loose fill surfacing over hard surfaces such as concrete or asphalt.

### Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles

You may be interested in using surfacing other than loose-fill materials -- like rubber tiles or poured-in-place surfaces.

- Installations of these surfaces generally require a professional and are not "do-it-yourself" projects.
- Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 *Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment*. This report should show the specific height for which the surface is intended to protect against serious head injury.


This height should be equal to or greater than the *fall height* - vertical distance between a designated play surface (*elevated surface for standing, sitting, or climbing*) and the protective surfacing below - of your play equipment.

- Check the protective surfacing frequently for wear.

### Placement

Proper placement and maintenance of protective surfacing is essential. Be sure to;

- Extend surfacing at least 6 feet from the equipment in all directions.
- For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.



# SAFETY

## INSTALLATION:

1. Follow the instructions provided, do not alter its design in any way.
2. Place the playset on level ground, not less than 6' (1.8m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires. If the area where you will be installing your playset is not level, you must make it level.
3. Playsets must be anchored to the ground. Follow the anchoring instructions provided with your building kit. If soil conditions permit anchors to be pulled out easily, such as in sandy soil conditions, cementing is required.
4. Tighten all bolts securely to the intended member then cut off all protruding threaded ends of bolts with a hack saw **flush to the end of the nut** and remove sharp edges with a metal file.

**WARNING:** Children must not use the playset until properly installed and proper shock-absorbing surfacing material is in place.

**OPERATION:** *Observing and following statements and warnings reduces the likelihood of serious or fatal injury.*

1. On-site adult supervision is recommended for children of all ages.
2. Only one child, for each single planned seat or single planned activity should be allowed on this set at one time, with a maximum weight of **105 pounds** for each child.

**WARNING:** You must teach children the following:

- A. **Not** to walk close to, in front of, behind, or between moving items.
- B. **Not** to twist swing chains or ropes or loop them over the top support bar since this may reduce the strength of the chain or rope.
- C. **Avoid** swinging empty seats.
- D. **To Sit** in the center of the swings with their full weight on the seats.
- E. **Not** to use the equipment in a manner other than intended.
- F. **Not** to get off equipment while it is in motion.
- G. **Not** to climb when equipment is wet.
- H. **Not** to attach items to the playground equipment that are not specifically designed for use with the equipment such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- I. **Remove** bike or other sports helmet before playing on the play equipment as the helmet may become entrapped in an enclosed opening and cause a

strangulation hazard.

3. Verify that suspended climbing ropes are secured at both ends and that they cannot be looped back on themselves. (A rope that is not taut enough may cause a strangulation hazard.)
4. Dress children appropriately. Provide well fitting shoes. Avoid ponchos, scarves, and other loose-fitting clothing which is potentially hazardous while using equipment.
5. Verify that all suspended swinging components have at least 8" clearance between the lowest point of component and top of shock-absorbing surfacing material.

**WARNING:** Lawn swings are designed for use by children two years of age and older. Use by children under the age of two can result in entrapment between the seat and backrest. **NEVER** place children in a rearward facing position or with legs between the seat and backrest because the child's body may pass through the opening causing entrapment of the child's head.

## DISPOSAL:

When the playset is to be retired from service, disassemble and dispose of in such a way that no unreasonable hazards will exist. Follow your local disposal requirements.

## ANNUAL MAINTENANCE CHECKLIST

(Copy this section as needed and maintain for your records or visit [www.playstarinc.com/maintenance](http://www.playstarinc.com/maintenance))



**At the beginning of play season:** Date: \_\_\_\_\_

- Tighten all hardware.
- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a nonlead-based paint meeting the requirements of 16 CFR 1303.
- Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.
- Reinstall any plastic parts, such as swing seats or any other items that were removed for the cold season.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

**Twice a month during play season:** Date: \_\_\_\_\_

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

**Once a month during play season:** Date: \_\_\_\_\_

- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.

**At the end of each play season or when the temperature drops below 0° F:** Date: \_\_\_\_\_

- Remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

**If any of these conditions exist, call 1-888-752-9782 for ordering information.**  
Clean plastic components with warm water and a mild detergent such as dish soap.

# TOOLS REQUIRED

Socket Wrench  
 5/16" Socket  
 9/16" or Adjustable Wrench  
 Ladder  
 Tape Measure  
 Safety Glasses  
 Utility Knife/Scissors

Drill/Driver (2 makes set up easier)  
 Saw Horses (Optional)  
 Square  
 Phillips Screwdriver  
 Hammer  
 1/8", 1/4" & 3/8" Drill Bit  
 1/4" Hex Bit Driver

#2 & #3 Screw Bit  
 Hack Saw  
 Metal File  
 Pencil  
 Tape  
 Level


# PURCHASE SEPARATELY

Exterior Paint  
 Exterior Stain  
 Permanent/Fabric Markers

Chalk  
 Floral Arrangements  
 Magnets


# HARDWARE INCLUDED (shown actual size)

*Additional hardware included All Quantities may not be used.*




# CONTENTS - 1


## Pre-Assembled Sections:




## Boards:



# CONTENTS - 2




Sunlight Window (1)




Decorate-A-Flag (1)




Flag Pole (1)




Magnetic Chalk Board (1)



Design-A-Plaque (1)




Sand Box Seat (1)



Roof Cap (2)




Zip Tie (1)



Swing Assembly (Yellow) (1)



Gym Ring Assembly (2)




Play Handles (2)




Discovery Telescope (1)




Playset Anchors (6)




Sturdy Frame Brace (1)




Corner Brackets (6)



Climbing Bars (4)



Climbing Rope (1)




Scoop Slide (1)



Stencil Kit (1)

# Remove Contents From Pallet

## STEP 1:



**Note:** An effort has been made to minimize packaging to reduce waste. Some of the materials used to secure playset to pallet will be repurposed during set up. Individual boards have been fastened inside pre-assembled sections.


Remove Component Box. Locate Torx bits supplied within hardware bags.

Detach Flower Box & Cupola from pallet using Torx bits supplied.

Remove screw from bottom of Flower Box (T-25).

Remove all screws from corner bracket on Cupola (T-20)


## STEP 2:




Remove screws using T-20 bit supplied.

Remove slide in direction of the arrow.

**STEP 3:**





**STEP 4:**



**STEP 5:**

Remove Rock Wall  
in direction of arrow  
rotating the top first




**STEP 6:**

Remove all 4 (four) corner brackets  
shown using T-20 bit supplied


**SAVE BRACKETS FOR LATER USE**

Remove Swing Beam Legs  
in direction of arrow



**STEP 7:**


Cut band



Remove 2 (two) Corner Brackets shown using T-20 bit supplied.  
**SAVE BRACKETS FOR LATER USE**

Remove 2" x 4" x 28 1/4" and Picnic Table in direction of arrow  
**SAVE 2" x 4" x 28 1/4" FOR LATER USE**


**STEP 8:**



Gently roll Tower to slide off pallet & keep in orientation as shipped.

**STEP 9:**

Remove all 8 (eight) 2" X 4" boards from pallet using T-25 bit supplied.



# ROOF ASSEMBLY



**Items for STEP 10:**

- (2) Roof Sides
- (2) Roof Caps
- (12) #14 x 1 1/4" pan head screws
- (3) #8 x 2" deck screws

On a flat surface position roof sides together as shown. Secure with #8 x 2" deck screws.

Position Roof Cap tight against boards as shown. Use Roof Cap as a drill guide and drill 1/8" holes 1" deep. Keep boards square while attaching Roof Cap to boards with #14 x 1 1/4" pan head screws. (#3 Screw Bit)

**Turn roof over. Repeat for second Roof Cap.**





Inside View

**Items for STEP 11:**

- (1) Cupola Template (Pg. 13)
- (1) Cupola Assembly

Set cupola at the desired location. Mark all six edges as shown. **(Fig. 1)**


Remove cupola. Cut out cupola template on facing page. Tape template on the roof, lining up the pencil edges. Locate and mark the four hole locations as shown. Drill  $\frac{1}{8}$ " holes through the roof. **(Fig. 2)**





**Items for STEP 12:**

- (4) #8 x 2 $\frac{1}{2}$ " deck screws

Align the cupola with the pencil marks. Using the previously drilled holes as a guide, predrill  $\frac{1}{8}$ " holes into the bottom of the cupola (from the inside of the roof). Secure from inside the roof with #8 x 2 $\frac{1}{2}$ " deck screws.



Cupola Template (cut out) used in Step 2 on Page 12.





This page  
Left  
Intentionally  
Blank

**Items for STEP 13:**

- (1) Flag
- (1) Flag Pole
- (1) Zip Tie

**Helpful Hint:** *Decorate or customize your flag with fabric markers or paint before placing on flag pole.*






Insert flag onto the flag pole with sewn edge on top as shown. Secure firmly with the zip tie. Trim the end of the zip tie with scissors flush with the head.

**Items for STEP 14:**

- (1) Flag Assembly
- (1) U-Strap
- (2) #14 x 1 1/4" pan head screws

At the location shown, drill a 3/8" hole at the top of the roof straight thru the roof as shown. **(Fig. 1)**

Slide the flag pole through the hole letting it rest on the roof cap. Secure with U-Strap as shown. Using the U-Strap as a pattern, drill 1/8" holes 1" deep into the board. Secure with #14 x 1 1/4" pan head screws.




### Items for STEP 15:

- (1) Roof Assembly
- (2)  $\frac{3}{8}$ " x 5" hex bolts
- (4)  $\frac{3}{8}$ " washers
- (2)  $\frac{3}{8}$ " lock nuts
- (4) #8 x 2 $\frac{1}{2}$ " deck screws

Position Roof Assembly so both sides of roof overhang tower posts equally. Secure top corners with two #8 x 2 $\frac{1}{2}$ " deck screws, then  $\frac{3}{8}$ " x 5" hex bolt,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts.


**See Bolt & Screw Placement Detail**



### Items for STEP 16:

- (2)  $\frac{3}{8}$ " x 5" hex bolts
- (4)  $\frac{3}{8}$ " washers
- (2)  $\frac{3}{8}$ " lock nuts
- (4) #8 x 2 $\frac{1}{2}$ " deck screws

Rotate tower 180° as shown. Verify the unattached side of the roof overhangs the tower posts equally. Secure the other two corners with #8 x 2 $\frac{1}{2}$ " deck screws, then  $\frac{3}{8}$ " x 5" hex bolt,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts.



# Climbers Assembly

## Items for STEP 17:

- (4) Climbing Bars
- (16) #14 x 1¼" pan head screws


Attach Climbing Bars at dimensions shown.

**Note: Side with 2" x 4" immediately below play deck**

Use the bar as a drill guide and drill ⅛" holes 1" deep into the board.

Attach with #14 x 1¼" pan head screws.

**Note: Location of your flag may be opposite side of roof.**




## Items for STEP 18:


- (1) 5/4" x 6" x 44¼" board
- (6) #8 x 2" deck screws

Lift tower upright and position in desired location.

Position board as shown.  
Secure with #8 x 2" deck screws.



5/4" x 6" x 44¼"



**Items for STEP 19:**

- (1) Rock Wall
- (2) Corner Brackets
- (4)  $\frac{3}{8}$ " x 2" hex bolts
- (8)  $\frac{3}{8}$ " washers
- (4)  $\frac{3}{8}$ " lock nuts
- (8) #8 x  $1\frac{1}{4}$ " deck screws
- (4) #8 x  $2\frac{1}{2}$ " deck screws

**Attach corner brackets.**

Position brackets 39" up from bottom of tower with the long side (Playstar logo) of the brackets against the 2" x 4" x 89" boards and the short side flush with the inside edges as shown. **(Fig. 1)**

Use brackets as a drill guide and drill  $\frac{1}{8}$ " holes 1" deep into the boards. Attach with #8 x  $1\frac{1}{4}$ " deck screws.


Again use brackets as a drill guide and drill  $\frac{3}{8}$ " holes completely through the boards. Secure with  $\frac{3}{8}$ " x 2" hex bolts,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts.

Attach rock wall to corner brackets as shown. Bottom corner of 2" x 4" x  $50\frac{1}{2}$ " board must rest on the ground and back edge of  $\frac{5}{4}$ " x 6" x  $21\frac{1}{2}$ " must be flush with the front of the 2" x 4" x  $28\frac{1}{4}$ " board.

Use brackets as a drill guide and drill  $\frac{1}{8}$ " holes 1" deep into the boards. Attach with #8 x  $1\frac{1}{4}$ " deck screws.

Again use brackets as a drill guide and drill  $\frac{3}{8}$ " holes completely through the Rock Wall support boards. Secure with  $\frac{3}{8}$ " x 2" hex bolts,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts.

Secure 2" x 4" x  $50\frac{1}{2}$ " boards to 2" x 4" x 89" boards. Drill  $\frac{1}{8}$ " holes 1" deep into the boards. Attach with #8 x  $2\frac{1}{2}$ " deck screws as shown. **(Fig. 2)**



# SWING BEAM ASSEMBLY

## Items for STEP 20:


- (2) Swing Beam legs
- (1) 2" x 4" x 60" board
- (1) 2" x 4" x 74" board
- (8) #8 x 2½" deck screws

Position assembly as shown.

**Note:** *Drilled ends of the Swing Beam legs at top.*

Align the Swing Beam legs so that the outermost points measure 88<sup>7</sup>/<sub>8</sub>" as shown.

Attach boards at dimensions shown.  
Secure with #8 x 2½" deck screws.



**Items for STEP 21:**

- (2) corner brackets
- (8) #8 x 1¼" deck screws
- (2) ⅜" x 3½" hex bolts
- (2) ⅜" x 2" hex bolts
- (8) ⅜" washers
- (4) ⅜" lock nuts


**Attach corner brackets.** To complete the A-Frame Assembly, flip over as shown and position brackets so that the short side (No PlayStar logo) is against the 2" x 4" x 60" board.

Use the bracket as a drill guide and drill ⅛" holes 1" deep into the board.  
Attach with #8 x 1¼" deck screws.

Again use the bracket as a drill guide and drill ⅜" holes completely through the boards.  
Secure with ⅜" hex bolts, ⅜" washers and ⅜" lock nuts.

**NOTE: If you are bolting through one board use a ⅜" x 2" hex bolt.**

**If you are bolting through two boards, use a ⅜" x 3½" hex bolt.**




**Items for STEP 22:**

- (1) Swing Beam
- (1) A-frame Assembly
- (1) Sturdy-Frame Brace
- (5)  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolts
- (10)  $\frac{3}{8}$ " washers
- (5)  $\frac{3}{8}$ " lock nuts



Lay swing beam on saw horses as shown. **(Fig. 1)**

**Fig. 1**



Position the A-frame assembly so that the top leg is above the top bracket and the bottom leg is below the bottom bracket. Line up the holes in the brackets with the holes in the posts and secure with  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolts,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts. **(Fig. 2)**

Install the Sturdy-Frame Brace as shown and secure with  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolt,  $\frac{3}{8}$ " washer and lock nut. **(Fig. 2)**




**Fig. 2**

## Step 22 Cont.:

Make sure brace is square to beam. Using the brace as a template, drill a  $\frac{3}{8}$ " hole completely through beam. **(Fig. 3)**

Secure the Sturdy-Frame Brace to the beam with a  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolt,  $\frac{3}{8}$ " washer and  $\frac{3}{8}$ " lock nut.





## Items for STEP 23:

- (1)  $\frac{3}{8}$ " x 5" hex bolt
- (2)  $\frac{3}{8}$ " washers
- (1)  $\frac{3}{8}$ " lock nut

Locate the hole on the 2" x 4" board of tower assembly where the Swing Station Assembly will be attached.

Position Swing Station Assembly against tower and secure with one  $\frac{3}{8}$ " x 5" hex bolt,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nut as shown.




**Items for STEP 24:**

- (1) Swing Beam leg
- (2)  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolts
- (4)  $\frac{3}{8}$ " washers
- (2)  $\frac{3}{8}$ " lock nuts

Position the Swing Beam leg on the single bracket so that the holes of the bracket line up with the holes in the single post as shown.

Secure with  $\frac{3}{8}$ " x  $3\frac{1}{2}$ " hex bolts,  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts as shown.



**Items for STEP 25:**

- (1) 2" x 4" x 28 $\frac{1}{4}$ " board
- (2) corner brackets
- (4) #8 x 2 $\frac{1}{2}$ " deck screws
- (8) #8 x 1 $\frac{1}{4}$ " deck screws
- (1)  $\frac{3}{8}$ " x 3 $\frac{1}{2}$ " hex bolt
- (3)  $\frac{3}{8}$ " x 2" hex bolts
- (8)  $\frac{3}{8}$ " washers
- (4)  $\frac{3}{8}$ " lock nuts


Attach 2" x 4" x 28 $\frac{1}{4}$ " board to Swing Beam leg and tower at dimensions shown. Secure using #8 x 2 $\frac{1}{2}$ " deck screws.

Position corner brackets as shown against the 2" x 4" x 28 $\frac{1}{4}$ " board.


Use the corner brackets as a drill guide and drill  $\frac{1}{8}$ " holes 1" deep into the board. Attach with #8 x 1 $\frac{1}{4}$ " deck screws.

Again use the corner brackets as a drill guide and drill  $\frac{3}{8}$ " holes completely through the boards. Secure with  $\frac{3}{8}$ " hex bolts (2" through one board and 3 $\frac{1}{2}$ " through two boards),  $\frac{3}{8}$ " washers and  $\frac{3}{8}$ " lock nuts.


Front View



Back View




Inside View



**Items for STEP 26:**

- (1) Picnic table


Mark and drill four  $\frac{1}{8}$ " holes on top board as shown. Mark 2 lines on bottom board as shown.



**Items for STEP 27:**

- (2) 2" x 4" x 30 1/2" boards
- (2) #8 x 2 1/2" deck screws


Align top outer edge of 2" x 4" x 30 1/2" boards with pencil marks as shown. Attach each board with only one #8 x 2 1/2" deck screw in the hole closer to the outer edge. Board should be able to pivot.



**Items for STEP 28:**

- (1) 2" x 4" x 35½" boards
- (4) #8 x 2½" deck screws


Attach Board at dimensions shown.  
Make sure board is level.  
Secure with #8 x 2½" deck screws.



**Items for STEP 29:**

- (1) 2" x 4" x 26½" boards
- (12) #8 x 2½" deck screws

From inside of Swing beam find center of 2" x 4" x 60" board. Position 2" x 4" x 26½" board 10¾" from center (21½" apart) as shown. Make sure boards are square. Secure with #8 x 2½" deck screws.




**Items for STEP 30:**

- (1) Picnic table assembly
- (6) #8 x 2½" deck screws

Attach picnic table to 2" x 4" x 60" as shown. Make sure table is centered. Secure with #8 x 2½" deck screws through the holes pre-drilled in Step 26 under decking.


Rotate legs as necessary to make sure table is level and legs are firmly resting on ground from underside of table. Secure with #8 x 2½" deck screws through the second holes left open during Step 27.



**Items for STEP 31:**

- (1) 2" x 4" x 60" board
- (4) #8 x 2½" deck screws

Attach 2" x 4" x 60" board at dimension shown. Center 2" x 4" x 60" board with Picnic Table and level with 2" x 4" x 74" board. Drill 2 (two) ⅛" holes on each leg as shown in Inside View below. Secure with #8 x 2½" deck screws.




**Items for STEP 32:**

- (4)  $\frac{5}{4}$ " x 6" x  $23\frac{7}{8}$ " boards
- (16) #8 x 2" deck screws

Attach first  $\frac{5}{4}$ " x 6" x  $23\frac{7}{8}$ " board flush with 2" x 4" x 74" and overhanging 1" from the end of 2" x 4" x 60" as shown. Secure with #8 x 2" deck screws.

Attach second  $\frac{5}{4}$ " x 6" x  $23\frac{7}{8}$ " board tight against the first one as shown. Secure with #8 x 2" deck screws.


**Repeat for other side mirroring boards.**



# FLOWER BOX

## Items for STEP 33:


Remove the  $\frac{5}{4}$ " x 6" x 21 $\frac{1}{2}$ " board from the front of Flower Box. Save the #8 x 2" deck screws.



## Items for STEP 34:


(2) #8 x 2 $\frac{1}{2}$ " deck screws

Set Flower Box at location Shown  
3" above 2" x 4" x 60".  
Pre-drill  $\frac{1}{8}$ " holes.  
Secure using #8 x 2 $\frac{1}{2}$ "  
deck screws.



## Items for STEP 35:

**Helpful Hint:** *Stencil or customize the face of your Flower Box before reattaching.*



# MAGNETIC CHALKBOARD


## Items for **STEP 36:**

- (1) Magnetic Chalkboard
- (4) #8 x  $\frac{5}{8}$ " truss head screws

Center Chalkboard on 2" x 4" x 26 $\frac{1}{2}$ " uprights.  
Secure with #8 x  $\frac{5}{8}$ " truss head screws.


**Caution:** To eliminate finger or head entrapments, all gaps around chalkboard & flower box - or to the nearest object - must meet the following guidelines:

- \*smaller than  $\frac{1}{4}$ "*
- \*between  $\frac{1}{2}$ " and  $3\frac{1}{2}$ "*
- \*or greater than 9"*



# STENCIL SET INSTRUCTIONS

1. Separate stencil strips into individual letters (fold at perforation to make separating letters easier). Keep letters organized in alphabetical order and remove the center of each letter.
2. A permanent marker (purchased separately) will work well for this project.
3. Test stencil your name or message on a piece of paper. Draw a bottom guideline on the paper. Stencil one letter at a time, starting with the first letter of the word. Space each of the following letters by placing the left edge of the stencil so it touches or slightly overlaps the previous letter.
4. Use your stencil test sheet to aid in the aligning your name or message on the supplied activities in your playset.
5. When you stencil on a supplied activity, align each stencil with the bottom edge. Lightly tape to hold stencil in place. Stencil each letter following the same procedure as you did on the test sheet. After stenciling all the letters, leave gaps in the letters open or fill in with the marker for your desired look.




# ANCHORING

## Items for STEP 37:

- (5) Anchors
- (5)  $\frac{3}{8}$ " x  $1\frac{1}{2}$ " Lag Screw
- (5)  $\frac{3}{8}$ " Washers


At locations shown screw Playset Anchors into ground by hand (a long screwdriver will help).

Use the anchor as a drill guide and drill a  $\frac{1}{4}$ " hole 1" deep into the board. Attach with  $\frac{3}{8}$ " x  $1\frac{1}{2}$ " lag screw and  $\frac{3}{8}$ " washer.



**Note:** If soil conditions permit anchors to be pulled out easily, such as in sandy soil conditions, cementing is required. If your ground is too hard to screw in the anchors, or you are having trouble lining up anchor with existing hole in tower, you can remove the earth with a shovel. Install the anchors and compact the earth as you replace it. Anchors must be placed below the level of the shock-absorbing surfacing material to prevent tripping or injury resulting from a fall.

**Reminder:** Be sure to install proper shock-absorbing surfacing material. Refer to the Safety Guide at the beginning of this plan.



# DESIGN-A-PLAQUE



## Items for STEP 38:

- (1) Design-a-Plaque
- (4) #8 x 1" truss head screws

Plaque can be installed horizontal or diagonal. Position plaque at desired location. Secure with #8 x 1" truss head screws.

### Helpful Hint:

*Decorate or customize your plaque before placing on your playset.*





# SUNLIGHT WINDOW ASSEMBLY

## Items for STEP 39:

- (1) Sunlight Window
- (16) #8 x 5/8" truss head screws

From the inside of the tower, center Sunlight Window flat in opening as shown. Secure with #8 x 5/8" truss head screws.




# SLIDE – Mounting Instructions

## Items for STEP 40:

- (1) PS 8813 Scoop Slide
- (3) #14 pan head screws


Align Slide at right angle (90°) to 48" play deck. Lip of Slide should rest on the play deck 1½". Using the Slide as a template, mark play deck through the three holes in the Slide. Drill three ⅜" holes at marked location.



Attach Slide temporarily to play deck with three #14 x 1¼" screws provided.

Prepare level area where Slide touches ground that is 1" below surrounding grade.

Locate and mark the ground on the back side, on either side of the star. Remove Slide and screw Playset Anchor into the ground (a long screwdriver will help). Screw the anchor deep enough so that the loop at the top of the anchor will be flat against the back surface of Slide when the Slide is in the final position.



Reinstall Slide permanently, attaching it to play deck using #14 x 1¼" pan head screws provided.

Use the Playset Anchor as a drill guide and drill a ⅜" hole completely through the Slide. Attach Slide to anchor with one ⅜" x 1¼" hex bolt, two ⅜" washers and one ⅜" lock nut provided in the anchor kit.

Fill in around bottom of Slide to make surface level to surrounding grade.

**Caution:** Failure to anchor the Slide properly could cause serious injury from children lifting the slide.


**Caution:** Do not install this Slide over concrete, asphalt, packed earth, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user.

# COMPONENTS – Mounting Instructions

## SWING SEAT • GYM RINGS

1. Attach coated ends of chains onto play component using Quick-Link Connectors provided. Tighten securely with an adjustable wrench.
2. Hook uncoated ends of chain onto Swing Hangers provided.
3. Customize the height of your **swing** or **gym rings** anywhere in the *Adjustment Zone*, to fit your child.

**Warning: Failure to tighten Quick Links securely could result in injury.**



### Swing Chain Spacing:

10" minimum spacing is required from the closest point of all other rides or stationary objects.

### Gym Ring Chain Spacing:

11½" minimum spacing is required from the closest point of all other rides or stationary objects.

## CLIMBING ROPE

1. Tie five knots, equally spaced, for climbing grips. (**Fig. 1**)
2. Insert rope through top hole and tie a knot with 4" remaining.
3. Insert opposite end through bottom hole, pull tight and tie a knot while keeping rope snug.
4. Secure both ends with staples provided (2 each end). (**Fig. 2**)





Fig. 1


## DISCOVERY TELESCOPE

1. Determine desired location for pivot.
2. Drill 1/8" diameter pilot hole 1" deep.
3. Fasten pivot with #8 x 2½" deck screw provided.
4. Snap Discovery Telescope onto pivot.




## SAND BOX SEAT

1. Position sand box seat as shown
2. Mark holes.
3. Drill 1/8" holes 1" deep into the boards.
4. Attach with #14 x 1¼" pan head screws.



## PLAY HANDLES

1. Position Play Handle at desired location.
2. Mark pilot holes.
3. Drill 1/8" holes 1" deep.
4. Secure with #14 x 1¼" pan head screws provided.





*Thank You for choosing PlayStar. Because it is our intention to make this a positive family experience, we have taken great care in preparing this product. Should you have any questions, or if we can assist you in any way, please call our friendly Customer Service Department for immediate action.*

Do not return to the store.  
**Please call us Toll Free at 1-888-PLAYSTAR**  
(752-9782)

Monday through Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

Ask for Customer Service.

**We Will Gladly Help!**



PlayStar, Incorporated, Janesville, WI 53547

© 2017, PlayStar, Inc. Reproduction of this document in part or whole is prohibited without the permission of PlayStar, Inc.

Protected by one or more of the following United States or Foreign Patents: US D418,189; US D409,708; US D424,154; US D428,637; US 6,402,663; US D422,332; US D410,059; US 6,068,557; US 6,302,801; US 6,482,095; US 6,039,654; US D410,060; US D424,649; US 6,361,445; CA 2,304,345; US 6,540,645; US 6,709,365; US 6,942,600; US D513,779; US 6,991,550; CA D109,228; CA D109,224; CA D109,225; CA 2,304,113; US 6,629,907; US D517,636; US D518,530; US D520,590; US 520,591; US D534,613; US 7,186,183; US 7,189,034; US 7,253,951; US D548,760; US 7,304,810; CA D109,227; CA D109,226; CA D112,355; CA D113,437; CA D113,442; CA D114,067; CA D114,068; CA 2,304,896; CA D119,674; US D573,222; US 7,419,437; CA 2,304,068; CA 2,488,576; US D580,507; US D585,570; CA 2,490,923; CA 2,304,341; US 7,594,875; CA 2,304,043; CA 2,529,276; CA 2,633,628; CA 2,633,056; US 7,594,875; CA 2,498,701; CA 2,495,136; CA 2,488,600